

BR 88UE/BR 88UB/BR 88UW BR 80UE/ BR 80UB / BR 80UW



Tips: Product design and specifications are subject to change without prior notice.

OUTLOOK AND INSTALL PAPER ROLL





Remove the used roll paper core if any, and insert a new roll paper. The correct direction of the paper is shown in the illustration above.

Button name, indicator LED light and function

0

FEED

STEP 1 - CONNECT PRINTER

Power Indicator:

Lights on means connected properly.

Error Indicator:


When out of paper, cutter or printing head overheat occurred, the ALARM indicator twinkles.

Paper Indicator(LED Light):

Blue and red lights are on means lack of paper, no alarm means normal.

Feed Button

Press to feed paper manually.



STEP 2 - INSTALL DRIVER

- A. Connect AC cable to the power adapter, DC power cable to the printer.
- B. Connect printer and computer/tablet.
- C. Connect cash drawer.

CONNECT PRINTER

CONNECT PRINTER

+ (**)


+ (**)

Self Test


Printer connected power and keep off status, then press the "FEED"button and turn on the power, after hear the beeper sounds, release "FEED button", first page will be printed, the second press in 2s for code page printing

TIPS


USB Port



LAN Port



CASH DRAWER PORT (Rj11 CABLE) The RJ11 cable



Code Page:

2:PC850(Multilingual)3:PC860(Portugal)

10:(Iran)11:(WPC1252) 12:PC866(Cyrillic#2)13:PC852(Latin2)

14:(PC858)15:(IranII)

16:(Latvian)17:(Arabic)

20:(WPC1257)21:(Thai)

22:(Vietnam)23:(PC864) 24:(PC1001)25:(Uigur)

26:(Hebrew)27:WPC1255(Israel)

28:PC437(Std. Europe)29:(Katakana) 30:PC437(Std. Europe)31:PC858(Mult)

36:PC865(Nordic)37;PC866(Russian)

40:PC862(Hebrew)41:PC864(Arabic)

46:PC772(Lithuanian)47:PC774(Lithuan)

48:PC874(Thai)49:WPC1252(Latin1)

52:PC3840(IBM-Russian) 53:PC3841(Gost)

56:PC3845(Hungarian)57:PC3846{Turkish) 58:PC3847(Brazil-ABNT) 59:PC3848(Brazil)

66:PC3021(Bulgarian)67:PC3041(Maltese)

0:PC437(Std. Europe)1:(Katakana)

4:PC863(Canadian)5:PC865(Nordic)

6:(West Europe)7:(Greek)

8:(Hebrew)9:(East Europe)

18:(PT1511251)19:(PC747)

32:PC 852(Latin-2)33:PC860(Portugu)

34:PC861(Icelandic)35:PC863(Canadian)

38:PC855(Bulgarian)39:PC857(Turkey)

42:PC737(Greek)43:PC851(Greek)

44:PC869(Greek)45:PC928(Greek)

50:WPC1250(Latin-2)51:WPC1251(Cyril)

54:PC3843(Polish)55:PC3844(CS2)

60:PC1001(Arabic)61:PC2001(Lithuan) 62:PC3001(Estonian-1)63:PC3002(Eston-2)


64:PC3011(Latvian-1)65:PC3012(Latv-2)


68:PC852(Croatia)69:VISCII 70:WPC1256(Arabic)

USB +Serial port driver installation



- 1. Double-click "POS Printer Driver V8.11"
- 2. USB driver installation or Serial port driver installation
- 1) Select USB port and printer type; 1) Select serial port, printer type and port number;





3) Select OK.

Code Page

4) Select YES to print the test page and check the printer driver name;



POS-580

Printer Interi


5) Installation is completed.

LAN port driver installation




- 1. Double-click "POS Printer Driver V8.11"
- 2. LAN driver installation

1) Select LAN port and printer type;



2) Click Start Installation.



3) Select YES to print the test page



4) Installation is completed.

Problems

Print random

Print font blur

The printer doesn't work

properly. The network

printed.

sounds.

Bluetooth

can't print

Incomplete

printing

FRRORLED


and PAPER LED are alway

on, and buzzer


Bluetooth driver installation



- 1. Double-click "POS Printer Driver V8.11"
- 2. Bluetooth driver installation
- 1) The computer is connected to the printer Bluetooth, Bluetooth name: Printer001 key: 0000



2) Select the Bluetooth port and printer type;



3) Click Start Installation.

You are using Windows 10 x64 OS. Please select Windows 10 to install.

O Windows 11

○USB ○COM

● POS-80C

OPOS-76C

Set Default Prin



English

5) Installation is completed.


O POS-76

WiFi driver installation



1. Double-click "Printer Test ' 2.WIFI driver installation

1) Insert USB cable, select USB connection, 2) Select network settings.



3) Set the IP of the printer WiFi (note that the IP needs to be set in the same gateway as the home network), and the printer is connected to the home network;

4) Use "POS Printer Driver V8.11" to install the driver, select the network port, printer type and IP port number;



If the wifi DHCP enable, ignore Step1



5) Click Start Installation

6) Select YES to print the test page and check the printer driver name



7) Installation is completed.

TROUBLESHOOTING

Possible Reasons

Character mismatch

Serial baud rate mismatch

Low printing density
 Poor quality of paper roll
 The life of the print head is r

Printer setup error

IP address conflict

the printer is not

covered properly;

2. Running out of

of printer Bluetooth

printing paper;

The upper cover of

Other Bluetooth devices

occupy the serial number

Paper setting is incorrect.

in font library, text

Solution and Suggestion

on-Chinese printing . Confirm whether the Chinese mode is turned on, if o, please use the tool to turn off the Chinese mode.

Operating instructions: 1. use "PrinterTest" to set up and connect the printer; 2. Enter the advanced mode-P 80 set DIP-Chinese mode-no-setting

Guidelines for page printing: print the self-check

printer; 2. Enter the advanced mode-set the default code page-enter the serial number of the code page character (please see the code page)-click set code page. Keep the baud rate of the device consistent with hat of the printer:

Print the self-check page to confirm the baud ate of the printer. please check "serial config".

Change the baud rate of computer serial port: ontrol panel-view devices and printers-right-

click printers-printer properties-ports-configure ports-modify baud rate-apply-OK;

1. Replace the paper roll
2. Modify the printing density: use
"Printer Test" to set, connect the printeradvanced - Density set- enter the density value
(the higher the value, the higher the density
value)-click set;
3. Replace the print head

estore factory settings; nstructions: Turn off the power of the printer press

instructions: up to the power of the primer press the "FEED" key-turn on the power at the same time-when The ERROR LED and the PAPER LED flash twice at the same time, release the "FEED" key, and the factory is successfully restored with a click;

Modify the printer IP address: use "PrinterTest" to set, connect the printer NEW IP-input IP-set New IP;

2. Replace the printing paper;

Uninstalling bluetooth device

Check the paper setting size

Check whether the upper cover is covered

Port Check

19200

Method (1)


Turn off the power and then restart.

Cutter stuck maintenance

Method (2)

Turn the gear on printing head, cutter can be returned to its original position.

CUTTER STUCK MAINTENANCE



Notice: To avoid the damage of the printing head and automatic paper cutter, please do not open cutter and mechanism violently.

CLEARANCE AND MAINTENANCE

Clearance

One of the following occurred, please clean printing head.

- (1) Printing is not clear.
- (2) Any vertical is not clear. (3) Paper feed noisily.

Printing head cleaning steps:

i iiitiiig i	icad cicalling	steps.
Parts to be cleaned	Step	Recommend cleaning frequency
Print head	1.Turn off the printer. 2.Allow the print head to cool for at least one minute. 3.Use a cotton swap and 100% ethanol to clean the print head surface.	When change new paper
	Print mechanism	Print head
Rubber roller	1.Turn off the printer. 2.Rotate the platen roller and use a cotton swap to clean with 100% ethanol.	When change new paper
Paper tear bar	Use a cotton swap and 100% ethanol to clean.	When necessary.
Sensor	Use air brush or vacuum to clean dust of sensor.	Monthly.
Inner side of printer	Use air brush or vacuum to clean the dust.	When necessary.

Notice

1)Please make sure power off when maintaining printer.
2)Don't touch or scratch printing head surface, roller and sensor
3)Avoid gas, acetone or other organic solvent.
4)Wait till alcohol completely volatilized, close top cover and connect power again. Try print self test to make sure it works

properly.



Warning
No part of this manual can be changed without agreement. The company reverses the right to modify the technologic, components, software and hardware. You may ask the distributors for more product information. No part of chapter in this manual can be copied or transmitted in any format without permission.

